

iBoard®

iBoard® by APS

PART#: IB-027A-B

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

***BODY FRAME MOUNT
*NO DRILLING REQUIRED**


Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST


Front
↑



Driver Front / Passenger Rear
Mounting Bracket (DFM/PRM)




Driver Front / Passenger Rear
Bar Bracket (DFB/PRB)




PFM/DRM

PFB/DRB

Passenger Front / Driver Rear
Mounting Bracket (PFM/DRM)



Passenger Front / Driver Rear
Bar Bracket (PFB/DRB)



DFM/PRM

DFB/PRB




Customer Support: info@iboardauto.com

iBoard®



STEP 1


Start installation from the driver side front of the vehicle. Locate on the backside of the rocker panel (3) mounting holes where the plastic fascia is cut out. Select (2) M8 Clip Nuts, line up the Clip Nuts with the holes. Locate a threaded hole above the clip nuts on the rocker panel. If equipped, remove plug to expose threaded hole. **NOTE:** Threaded nut on Clip nut must face inside of the side panel, (Fig 1).



(Fig 1) Driver Side Front Mounting Bracket Installation Pictured

STEP 2

Select (1) Driver Front Mounting Bracket (**DFM/PRM**) and (1) Driver Front Bar Bracket (**DFB/PRB**). Assembly with (2) M8X1.25-25mm Hex Bolts, (2) M8 Lock Washers, (4) M8 Flat Washers and (2) M8 Hex Nuts, (Fig 2). Do not fully tighten at this time.



(Fig 2) Driver Front Mounting Bracket Assembly

STEP 3

Attach (1) Driver Front Mounting Bracket (**DFM/PRM**) to the installed M8 Clip Nuts with the included (2) M8X1.25-30mm Hex Bolts, (2) M8 Lock Washers and (2) M8 Large Flat Washers, to the threaded hole using (1) M8X1.25-30mm Hex Bolt, (1) M8 Lock Washers and (1) M8 Large Flat Washer, (Fig 3). Do not fully tighten at this time.

iBoard®

STEP 5


Select a Running Board. Slip (4) M6X1-20mm Square Head Bolts into each bottom channel (Fig 5). Carefully position the Running Board onto the (2) Mounting Brackets.

IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (4) M6x1-20mm Square Head Bolts, (4) M6 Large Flat Washers and (4) M6 X1 Nylon Lock Nuts (Fig 6). Do not fully tighten at this time.




(Fig 5) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

- (4) M6X1-20mm Square Head Bolts
- (4) M6 Large Flat Washers
- (4) M6X1 Nylon Lock Nuts




(Fig 6) Running Board Installed Onto the Mounting Bracket



(Fig 3) Driver Front Mounting Bracket Installation

STEP 4

Move to the driver side rear mounting location. Repeat Steps 1—3 to assemble and install (1) Driver Rear Mounting Bracket (PFM/DRM) and (1) Driver Rear Bar Bracket (PFB/DRB), (Fig 4). Do not tighten hardware at this time.



(Fig 4) Driver Rear Mounting Bracket Assembly

iBoard®

STEP 6

Level and adjust the Running Board and fully tighten all hardware.

STEP 7

Repeat **Steps 1-6** for other side Running Board installation. The installation is completed (**Fig 7**).



(Fig 7) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.