

iBoard®

iBoard® by APS


PART#: IB-R934A_B

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

***ROCKER PANEL MOUNT
*NO DRILLING REQUIRED**

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST



Customer Support: info@iboardauto.com

iBoard®



M8X1.25-
20mm Hex Bolt



M6X1-20mm
Square Head Bolt



M6 Large Flat
Washer




M6X1 Nylon
Lock Nut

STEP 1

Start installation at the driver side of the vehicle.

Locate the (3) factory mounting hole locations on the underside of vehicle rocker panel. Attach Driver Front Mounting Bracket (DFM) to the first set of mount holes closest to the front of vehicle with (2) M8X1.25-20mm Hex Bolts. Don't fully tighten at this time, (Fig 1).

Note: The (2) Front Mounting Brackets are different with (4) Center and Rear Mounting Brackets.




(2) M8X1.25-20mm Hex Bolts

(Fig 1) Driver Front Mounting Bracket (DFM) Installation

STEP 2

Move to the Center & Rear mounting locations. Repeat **Step 1** to install Center & Rear Mounting Brackets. Do not fully tighten at this time, (Fig 2).



(2) M8X1.25-20mm Hex Bolts

(Fig 2) Driver Center & Rear Mounting Brackets Installation


STEP 3

Select a Running Board. Slip (3) M6x1-20mm Square Head Bolts into each bottom channel (Fig 3). Carefully position the Running Board onto the (3) Mounting Brackets.


IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6X1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts (Fig 4). Do not fully tighten at this time.

iBoard®

M6X1-20mm Square Head Bolts



(Fig 3) Slip (3) M6X1-20mm Square Head Bolts Into Each Bottom Channel



(2) M6X1-20mm Square Head Bolts
(2) M6 Large Flat Washers
(2) M6X1 Nylon Lock Nuts

(Fig 4) Running Board Installed Onto Mounting Bracket

STEP 4

Level and adjust the Running Board and fully tighten all hardware.

Important: Please follow the recommended Tightening Torques shown in the table on page 1. Don't over tighten, or the nuts/bolts will be damaged.

STEP 5

Repeat **Steps 1-4** for the other side Running Board installation. The installation is completed (Fig 5).



(Fig 5) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.