



Part#	HT-X32775	Application	Nissan Frontier Long bed					
Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)	1#	Hex Bolts	8	M10X1.5-35	5#	Hex Bolts	2	M12X1.75-40
	2#	Large Flat Washers	4	M10	6#	Conical Washers	2	M12
	3#	Conical Washers	4	M10	7#	Nut Plate Weldnut	2	
	4#	Hex Flange Nuts	4	M10X1.5				
HW A (For Hitch Assembly)	8#	Hex Bolts	8	M12X1.75-35	10#	Hex Flange Nuts	8	M12X1.75
	9#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch: 5000 LBS. Trailer Weight & 500 LBS. Tongue Weight.
Gross Load Capacity When Used As A Distribution Carrying Hitch: 6000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

Diagram A illustrates the mounting of the bumper bracket to the frame. The bumper bracket is shown being aligned with the existing frame holes on both sides. The mounting is secured by screws. A label 'C' points to the bumper bracket. The text 'ALIGN PLATE WITH EXISTING FRAME HOLES (BOTH SIDES)' and 'MOUNTS TO INSIDE OF BUMPER BRACKET AS SHOWN' are included as instructions.

The instructions here are for your reference only. We strongly recommend professional installation for best results. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instructions

Part#	HT-X32775	Application	Nissan Frontier Long bed
Step	Description		
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts. (Hardware in “HW A”). Note: Torque all HWA to 86 lb-ft		
2	Insert nut plate into the frame on both sides. Align the holes in the frame with nut plates.		
3	Raise the hitch into position. Loosely attach hitch to frame at mounting locations near the bumper with the M12 hex bolts provided. Use M10 hex bolts in remaining fastener locations as shown.		
4	Torque all M10 fasteners to 50 lb-ft. and all M12 fasteners to 86 lb-ft.		
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.			

The instructions here are for your reference only. We strongly recommend professional installation for best results. We are not responsible for any damage caused by the installation. Thank you for choosing our product!