



Hitch Installation Instructions


REV.20260601D

Part#	HT-X36470	Application	Dodge Ram 1500 Van / Ram 2500 Van / Ram 3500 Van With Factory Step Bumper					
-------	-----------	-------------	---	--	--	--	--	--

Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
	1#	Fish Wire	1	L=762	3#	Spacers	6	With SQ Hole
HW B (For Hitch Installation)	2#	Hex Flange Nuts	6	M12X1.75	4#	Carriage Bolts	6	M12X1.75-45
	5#	Hex Bolts	8	M12X1.75-35	7#	Hex Flange Nuts	8	M12X1.75
HW A (For Hitch Assembly)	6#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch: 6000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch: 10000 LBS. Trailer Weight & 1000 LBS. Tongue Weight.
DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

* No Drilling Required



The instructions here are for your reference only. We strongly recommend professional installation for best results. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instructions

Part#	HT-X36470	Application	Dodge Ram 1500 Van / Ram 2500 Van / Ram 3500 Van With Factory Step Bumper
Step	Description		
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts. (Hardware in “HW A”). Note: Finger tighten only. Do not fully tighten at this time.		
2	Locate mounting holes and the access hole in bottom of each frame rail. Fish wire the carriage bolts and spacers up through the access hole and down into the holes in the frame.		
3	If the vehicle has a heat shield remove one screw from the bottom of the frame rail so the bracket will sit flat on the bottom of the frame.		
4	Raise hitch into position. Torque M12 carriage bolts to 58 lb-ft and other M12 fasteners to 86 lb-ft.		
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.			

The instructions here are for your reference only. We strongly recommend professional installation for best results. We are not responsible for any damage caused by the installation. Thank you for choosing our product!