

iBoard®

iBoard® by APS


PART#: IB-195[S]-A_B

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

***ROCKER PANEL MOUNT
*NO DRILLING REQUIRED/CUTTING MAYBE REQUIRED**

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST




Customer Support: info@iboardauto.com

iBoard®



STEP 1

Start the installation under the driver side of the vehicle. Locate the 3 tabs along the bottom edge of the body, (pinch weld). Mounting Brackets will bolt to the 1st, 2nd and 4th mounting tabs, (Fig 1). Directly above each tab is a top mounting location on the side of the body panel. Hold a Bracket up in place to help determine the mounting holes to use along the body.



(Fig 1) Back Of Driver Side (3) Mounting Locations

STEP 2

Determine the correct procedure for your model year and each Bracket location.

Lower mounting location on the edge of the pinch weld.

***Flat tab on pinch weld with factory installed weld nut:**

Thread M8 Hex Bolt into weld nut from the backside-down to clear paint from threads, (Fig 2).

***Flat tab on pinch weld with hole:**

Select (1) M8 Clip Nut. Slide the M8 Clip Nut over the tab with the nut facing up behind the tab, (Figs 3—5). Line up threaded nut with hole in tab. Repeat for each mounting location.


Upper mounting location on the back side of the body panel.

***Models with factory installed threaded insert in body panel:**

Thread M8 Hex Bolt into threaded insert to clear paint as required, (Fig 2 & 3).


***Large and small hole in side of body panel:**

Remove the rubber plug from the larger hole, (Fig 4). Select (1) M8 Clip Nut. Slide the M8 Clip Nut into the larger hole. Line up the threaded nut with the smaller hole, (Fig 5).




(Fig 2) Driver Front Mounting Bracket Location


iBoard®



(Fig 3) Driver Center Mounting Bracket Location




(Fig 4) Driver Center Mounting Bracket Location
(With Rubber Plug on Mounting Hole)




(Fig 5) Driver Rear Mounting Bracket Location

STEP 3

Assemble Driver Front Mounting Bracket and Driver Front Mounting Plate as shown (Fig 6). And then Bolt the Assembled Mounting Bracket to the M8 Clip Nuts and/or the factory threaded holes on Driver Side Front Mounting Location with (2) M8 x1.25-25mm Hex Bolts, (2) M8 Lock Washers and (2) M8 Large Flat Washers, (Fig 7). Snug but do not fully tighten the hardware.



(Fig 6) Driver Front Mounting Bracket Assembled



(Fig 7) Assembled Driver Front Bracket Installed

STEP 4

Repeat **Steps 1—3** to install the (2) remaining driver side Brackets.

iBoard®

STEP 5


Select a Running Board. Slip (3) M6x1-20mm Square Head Bolts into each bottom channel (**Fig 16**). Carefully position the Running Board onto the (3) Mounting Brackets. **IMPORTANT:** Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged.

Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts (**Fig 17**). Do not fully tighten the hardware at this time.



(Fig 16) Slip M6X1-20mm Square Head Bolts into the bottom channel

(2) M6X1-20mm Square Head Bolts
(2) M6 Large Flat Washers
(2) M6X1 Nylon Lock Nuts



(Fig 17) Running Board Installed Onto Mounting Brackets

STEP 6

Level and adjust the Running Board as necessary and fully tighten all hardware.

STEP 7

Move to the passenger side of the vehicle. On the passenger side, determine if the vehicle is equipped with a plastic diesel exhaust fluid (DEF) tank, (**Fig 8 & 9**).

Models without DEF tank, skip to Step 8.


Models with DEF tank: The tank sits close to the side of the body. With specialized tools, the Passenger Front Mounting Bracket can be installed but room is limited. It may be easier to drop the tank down to access the inner side of the body panel for bracket installation. Tank will not need to be removed, only dropped down for access to mounting location.

IMPORTANT: If tank is full, it will be very heavy and assistance is highly recommended to avoid injury or damage to the vehicle or the tank. It is recommended that installation is performed when the DEF tank is low on fluid before dropping the tank.

- For 07-16 Models:** with plastic lower tray under the tank, remove the (3) hex bolts attaching the tray to the frame, (**Fig 8**), and remove the tray. **For 2017-Up 2500/3500 models:** Remove the (4) hex bolts attaching the plastic cover to DEF tank, (**Fig 9A**) and remove the plastic cover, (**Fig 9B**).
- Release the tank filler hose. Release the plug for the sending unit on the top of the tank.
- Support the tank with a floor jack. Place a smooth flat surface, (wooden block for example), between the floor jack and the tank to avoid damaging the plastic tank. Do not push up on the tank; only support the weight of the tank with the jack.
- Remove the (2) bolts securing the tank straps to the vehicle, (**Fig 10**). Tilt the straps to release from the brackets. Slowly lower the tank until the top of the tank is almost visible. Use blocks or stands to support the tank while installing the front Brackets.
- Proceed to **Step 8**.


iBoard®

Remove (3) Hex Bolts
To Remove Cover




(Fig 8) 07-16 Passenger Side Front Pictured With DEF Tank Cover

Remove (4) Hex Bolts To
Remove Plastic Cover




(Fig 9A) 2017-Up Passenger Side Pictured With DEF Plastic Tank Cover



(Fig 9B) 2017 Passenger Side DEF Cover Removed

Remove (2) Factory Bolts
To Remove Tank Straps



(Fig 10) 07-16 Passenger Side DEF Tank And Cover

STEP 8

Locate the first tab on the edge of the pinch weld, attach the Passenger Front Mounting Bracket (PFM) to the pinch weld and top body panel (Fig 11 & 12):

- Models with flat tab and hole:** see Fig 11. Leave loose at this time.
- Models with weld-nut:** see Fig12. Leave loose at this time.


Models With Hole :
M8 x1.25-35mm Hex Bolt
M8 Lock Washers
M8 Large Flat Washer



(Fig 11) Passenger Front Mounting Bracket Installed

Models With 8mm Threaded
Insert In Body Panel:
M8 x 1.25-25mm Hex Bolt
M8 Lock Washer
M8 Large Flat Washer

Models With Weld Nut On
Pitch Weld:
M8 x 1.25-25mm Hex Bolt
M8 Lock Washer
M8 Large Flat Washer




(Fig 12) Passenger Front Mounting Bracket Installed (Weld Nut If Equipped-Also See Fig 2)

iBoard®


STEP 9

Repeat **Steps 2—4** for the (2) remaining passenger side mounting brackets installations.


2017-up 2500/3500 DEF tank models: Locate the 2nd tab bracket location along the bottom edge of the body, (pinch weld), (**Fig 13**). Hold the DEF cover in place and mark the 2nd Bracket location onto the cover, (**Fig 14**). Use a sharp knife or hacksaw blade to carefully cut a slot in the plastic cover to clear the 2nd Bracket, (**Fig 15**). Remove as little plastic as possible.



(Fig 13) Passenger 2nd Mounting Bracket Location From Back Of Body Panel



(Fig 14) 2017-Up Passenger Side DEF Cover Marked For Trimming



(Fig 15) 17-Up Passenger Side DEF Cut For Example Only

STEP 10

Repeat **Steps 5 & 6** to install the passenger side Running Board installation.

STEP 11

Once the Running Board are installed and all hardware fully tightened, reinstall the DEF tank and cover, if equipped, as described in **Step 7**.

The installation is completed (**Fig 18**).



(Fig 18) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.