

# iBoard®

## iBoard® by APS

PART#: IB-212A-B

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.


\*ROCKER PANEL MOUNT  
\*NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94


### PART LIST




Front




Driver Front / Passenger Rear Mounting Bracket (DFM/PRM)



Passenger Front / Driver Rear Mounting Bracket (PFM/DRM)



PFM/DRM



DFM/PRM



**Note:** \*Driver Front/Passenger Rear Mounting Bracket Are Universal  
\*Passenger Front/Driver Rear Mounting Bracket Are Universal

Customer Support: [info@iboardauto.com](mailto:info@iboardauto.com)

# iBoard®



M8X1.25-30mm Hex Bolt



M8X1.25-25mm Hex Bolt



M8 Large Flat Washer



M8 Flat Washer



M8 Lock Washer



M8X1.25 Hex Nut



M8 Clip Nut



M6X1-20mm Square Head Bolt




M6 Large Flat Washer



M6X1 Nylon Lock Nut

## STEP 1


Starting on the driver side of the vehicle, locate the (2) holes in the bottom of the body panel, (pinch weld), toward the front tire, **(Fig 1)**. Next locate the rectangular opening and (2) small holes in the inner body panel directly above the holes in the pinch weld, **(Figs 1 & 2)**. **NOTE:** The holes in the inner panel may be covered with sealing tape or insulation.



**(Fig 1) Driver Inner Body Panel Illustrated**

## STEP 2

Slide (1) M8 Clip Nut into the rectangular opening with the nut towards the inside. Line up the threaded nut on the clip with the round hole, **(Fig 2)**. Repeat to install the 2nd M8 Clip Nut in remaining hole location.



**(Fig 2) Slide M8 Clip Nuts Over Holes**


## STEP 3

Starting installation from the driver side front of the vehicle. Select (1) Driver Front Mounting Bracket (**DFM/PRM**), attach the Mounting Bracket to the (2) M8 Clip Nuts with the included (2) M8x1.25-30mm Hex Bolts, (2) M8 Lock Washers and (2) M8 Large Flat Washers, **(Figs 3 & 4)**. Depending on model and year, the brake cable may be run on the inside or outside of the Bracket. Do not fully tighten hardware at this time.

**NOTE:** The cradle on the front Bracket should face to the rear of the vehicle.

# iBoard®

- (2) M8x1.25-30mm Hex Bolts
- (2) M8 Lock Washers
- (2) M8 Large Flat Washers




(Fig 3) Driver Front Mounting Bracket Installation

## STEP 4

Align the bottom holes in the Driver Front Mounting Bracket with the (2) holes in the pinch weld. Bolt the Bracket to the pinch weld using the included (2) M8x1.25-25mm Hex Bolts, (4) M8 Flat Washers, (2) M8 Lock Washers and (2) M8 Hex Nuts, (Fig 4). **NOTE:** Insert the bolts up from the bottom of the pinch weld and through the Bracket. Do not fully tighten hardware at this time.

- (2) M8x1.25-25mm Hex Bolts
- (4) M8 Flat Washers
- (2) M8 Lock Washers
- (2) M8 Hex Nuts



- (2) M8x1.25-30mm Hex Bolts
- (2) M8 Lock Washers
- (2) M8 Large Flat Washers

(Fig 4) Driver Front Mounting Bracket Installation

## STEP 5

Continue along the cab to the rear mounting location. Locate the last (2) mounting holes in the pinch weld towards the back of the cab, (Fig 1). Repeat **Steps 2—4** for Driver Rear Mounting Bracket (PFM/DRM) installation. **NOTE:** The cradle on the rear Bracket should face the front of the vehicle. Do not fully tighten hardware at this time.

## STEP 6

Select a Running Board. Slip (2) M6x1-20mm Square Head Bolts into each bottom channel (Fig 5). Carefully position the Running Board onto the (2) Mounting Brackets.


**IMPORTANT:** Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts (Fig 6). Do not fully tighten hardware at this time.



(Fig 5) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

# iBoard®

- (2) M6X1-20mm Square Head Bolts
- (2) M6 Large Flat Washers
- (2) M6X1 Nylon Lock Nuts



(Fig 6) Running Board Installed Onto Driver Center Mounting Bracket

## STEP 7

Level and adjust the Running Board and fully tighten all hardware.

## STEP 8

Repeat **Steps 1-7** for the other side Running Board installation. The installation is completed (**Fig 7**).



(Fig 7) Installation Completed

### Attention

**Do periodic inspections to the installation to make sure that all hardware is secure and tight.**

**In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.**