

# iBoard®

## iBoard® by APS

PART#: IB-105A-B





READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

\*BODY FRAME MOUNT  
\*NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

### PART LIST

Front  
↑




Driver Rear Bar Bracket (DRB)

Passenger Rear Bar Bracket (PRB)



Customer Support: [info@iboardauto.com](mailto:info@iboardauto.com)


# iBoard®



## STEP 1

Start installation from the driver side front of the vehicle. Locate the Driver Front Mounting Bracket (DFM) location, (Fig 1A).


Select (1) M10 Double Nut Plate, (Fig 1B). Insert the M10 Double Nut Plate into the large round hole in the floor panel. Line up the (2) threaded nuts on the M10 Double Nut Plate with the large round hole and the oval hole on the floor panel.



(Fig 1A) M10 Double Nut Plate Installation  
Driver Front Mounting Bracket (DFM) Location

## STEP 2

Select the Driver Front Mounting Bracket (DFM). Attach the Bracket to the installed M10 Double Nut Plate with (2) M10X1.5-30mm Hex Bolts, (2) M10 Lock Washers and (2) M10 Flat Washers (Fig 2). Do not fully tighten hardware at this time.



(Fig 2) Driver Front Mounting Bracket (DFM) Installation


## STEP 3

Next, move to the driver side rear of the vehicle. Assemble (1) Driver Rear Mounting Bracket (DRM) and (1) Driver Rear Bar Bracket (DRB) with (1) M12X1.75-35mm Hex Bolt, (2) M12 Flat Washers, (1) M12 Lock Washer and (1) M12 Hex Nut, (Fig 3). Do not fully tighten hardware at this time.

# iBoard®

## STEP 5

Next, attach the assembled Driver Rear Mounting Bracket (**DRM**) to M10 Single Nut Plate with (1) M10X1.5-30mm Hex Bolt (lower nut plate hole), (1) M10X1.5-25mm Hex Bolt (top nut plate hole), (2) M10 Lock Washers, and (2) M10 Flat Washers, (**Fig 5**). Do not fully tighten hardware at this time.




(Fig 5) Driver Rear Mounting Bracket (DFM) Installation

## STEP 6

Select a Running Board. Slip (2) M6x1-20mm Square Head Bolts into each bottom channel (**Fig 6**). Carefully position the Running Board onto the (2) Mounting Brackets.

**IMPORTANT:** Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to Mounting Bracket with (4) M6x1-20mm Square Head Bolts, (4) M6 Large Flat Washers and (4) M6 X1 Nylon Lock Nuts (**Fig 7**). Do not fully tighten hardware at this time.




(Fig 3) Driver Rear Mounting Bracket Assembly

## STEP 4

Locate the Driver Side Rear Mounting Location, (**Fig 4**). Select (1) M10 Single Nut Plate, insert the flat end of the M10 Single Nut Plate (No welded nut) into the frame. Line up the threaded holes and welded nut on the M10 Single Nut Plate with the (2) holes on the frame, (**Fig 4**).

**NOTE:** Make sure the welded nut side of the Nut Plate is facing up.




(Fig 4) M10 Single Nut Plate Installation  
(On the Driver Side Rear Mounting Location)

# iBoard®



(Fig 6) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

(2) M6X1-20mm Square Head Bolts  
(2) M6 Large Flat Washers  
(2) M6X1 Nylon Lock Nuts




(Fig 7) Running Board Installed Onto the Mounting Bracket

## STEP 7

Level and adjust the Running Board as necessary and fully tighten all hardware.

## STEP 8

Move to the passenger side of the vehicle. Remove the (2) Factory Hex Bolts on the cover over the air conditioning lines located by the front fender, (Fig 8). Hold the Passenger Front Mounting Bracket (PFM) in position over the (2) holes and secure it with the (2) Factory Hex Bolts. Do not fully tighten hardware at this time.



(Fig 8) Passenger Side Front Mounting Location

## STEP 9

Repeat **Steps 3-5** for Passenger Rear Mounting Bracket (PRM) and Passenger Rear Bar Bracket (PRB) assembly and installation. Do not fully tighten hardware at this time.

## STEP 10

Repeat **Steps 6-7** for the passenger side Running Board installation. The installation is completed, (Fig 9).



(Fig 9) Installation Completed

### Attention

**Do periodic inspections to the installation to make sure that all hardware is secure and tight.**  
**In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.**