

# iBoard®

## iBoard® by APS

PART#: IB-060A-B


**READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.**

**\*BODY FRAME MOUNT  
\*NO DRILLING REQUIRED**


Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

### PART LIST


Front  
↑




Driver Front Mounting Bracket (DFM)



Passenger Front Mounting Bracket (PFM)



Driver Rear Mounting Bracket (DRM)



Passenger Rear Mounting Bracket (PRM)




Customer Support: [info@iboardauto.com](mailto:info@iboardauto.com)

# iBoard®



## STEP 1

Start installation from the driver side front of the vehicle. Locate the factory rectangular hole on the inner side of the frame behind the front body mount, (Fig 1).




(Fig 1) Driver Side Front Mounting Location


## STEP 2

Select the M12 Long Bolt Plate, (Fig 3B). Insert the M12 welded bolt on the Bolt Plate into the rectangular hole on the frame through the opening end of the frame, (Fig 2 & 3A).

**NOTE:** The Long Bolt Plate is for driver side front and the Short Bolt Plate is for passenger side front.



(Fig 2) The Opening End of the frame (Driver Side Front)




(Fig 3A) Inside View Of M10 Long Bolt Plate Installed (In Driver Side Frame Channel)

# iBoard®

## STEP 3

Attach the Driver Front Mounting Bracket (DFM) to the installed M12 Long Bolt Plate with (1) M12 Flat Washer, (1) M12 Lock Washer and (1) M12 Hex Nut, (Fig 4). Do not fully tighten hardware at this time.




(Fig 4) Driver Front Mounting Bracket (DFM) Installation

## STEP 4


Move to the Driver Side Rear Mounting Location. Locate the factory rectangular on the frame below the rear body mount, (Fig 5).

Select the Driver Rear Mounting Bracket (DRM). Attach the Rear Mounting Bracket to the vehicle with (1) M12X1.75-45mm Hex Bolt, (2) M12 Flat Washer, (1) M12 Lock Washer and (1) M12 Hex Nut, (Fig 6). Do not fully tighten hardware at this time.



(Fig 5) Driver Side Rear Mounting Location

- (1) M12X1.75-45mm Hex Bolt
- (2) M12 Flat Washers
- (1) M12 Lock Washer
- (1) M12 Hex Nut



(Fig 6) Driver Rear Mounting Bracket (DRM) Installation

## STEP 5

Select a Running Board. Slip (2) M6X1-20mm Square Head Bolts into each bottom channel (Fig 7). Carefully position the Running Board onto the (2) Mounting Brackets.


**IMPORTANT:** Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts (Fig 8). Do not fully tighten at this time.

# iBoard®



(Fig 7) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

- (2) M6X1-20mm Square Head Bolts
- (2) M6 Large Flat Washers
- (2) M6X1 Nylon Lock Nuts



(Fig 8) Running Board Installed Onto the Mounting Bracket

## STEP 6

Level and adjust the Running Board and fully tighten all hardware.

## STEP 7

Repeat **Steps 1-6** for other side Running Board installation. The installation is completed (**Fig 9**).



(Fig 9) Installation Completed

### Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.