



Hitch Installation Instruction


REV.20250901

Part#	HT-X30203	Application	For 2015-2022 Chevrolet Colorado All\2015-2022 GMC Canyon All						
Hardware List		Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
(For Hitch Assembly)	HW A	1#	Hex Bolts	6	M12X1.75-35	3#	Lock Washers	6	M12
		2#	Flat Washers	10	M12	4#	Hex Nuts	4	M12
<p>Gross Load Capacity When Used As A Weight Carrying Hitch: 6000 LBS. Trailer Weight & 900 LBS. Tongue Weight. Gross Load Capacity When Used As A Weight Distribution Hitch: 8000 LBS. Trailer Weight & 900 LBS. Tongue Weight ***DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. ***</p>									
<p>NOTE: REUSE FACTORY MOUNTING HARDWARE AND MOVE CLIP NUTS TO SPARE TIRE SUPPORT BRACKET</p>								<p>* No Drilling Required</p>	
<p>WELDNUT CLEANING To remove debris from weldnuts in frame, spray lubricant or compressed air into hole. For heavy debris, use a small wire brush. (Be careful not to damage threads).</p>									

The instruction here is for your reference only. We strongly recommend the professional installer for best result.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

Part#	HT-X30203	Application	For 2015-2022 Chevrolet Colorado All\2015-2022 GMC Canyon All
Step	Description		
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (6) M12X1.75-35 Hex Bolts, (10) M12 Flat Washers, (6) Lock Washers, (4) M12 Hex Nuts.(Hardware in "HW A"). Note: Finger tighten only. Do not fully tighten at this time.		
2	Lower spare tire using the vehicle service tools located in the cab of the truck. Loosen the spare tire support bracket by removing (2) bolts with a 13mm socket by the spare winch. Remove the 2 bolts from the factory hitch or cross member and transfer the (2) clip nuts onto the spare tire support bracket.		
			
3	Remove (4) bolts securing the factory cross member or hitch to the frame rail with a 21mm socket. Set hardware aside for reuse during hitch installation. Note: The bumper shares the same mounting points and should be supported from underneath.		
			
4	Check to be sure that all wiring clears and slowly pull factory cross member or hitch downward and remove from vehicle. Clean weldnuts as needed with lubricant and brush. Replace with hitch, which will mount in the space between the frame and the bumper mounting plates.		
			
5	Using the existing mounting hardware, attach the bottom mounting bolts (2 places each side) and loosely secure so that bumper placement adjustments can be made. Adjust bumper position to align with side mounting holes and secure remaining (4) bolts with a 21mm socket.		

The instruction here is for your reference only. We strongly recommend the professional installer for best result.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

Part#	HT-X30203	Application	For 2015-2022 Chevrolet Colorado All\2015-2022 GMC Canyon All
			
6	Torque all M14 bolts to 126 ft-lbs.		
7	Reinstall all bolts loosened / removed in step 1. Raise the spare tire back into position.		
<p>***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.</p>			

The instruction here is for your reference only. We strongly recommend the professional installer for best result.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!