


Hitch Installation Instruction

REV.20240901



The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Part#	HT-X30985	Application	For 2000-2006 Toyota Tundra\Excludes towable bumper models	
Step		Description		
1		Assemble Hitch Body (A) and Mounting Brackets (B , C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts.(Hardware in " HW A ").		
2	Remove two f	Remove two fascia cups on bumper and return to owner.		
3	Raise hitch into position.			
4	Install (2) M12X1.25-40 hex bolts. (hand tighten).			
5	Install (2) M12X1.75-90 hex bolts with washers into bumper and tighten.			
6	Install (2) M12	Install (2) M12X1.75-50 carriage bolts with square hole spacer and hex flange nut.		
7	Torque M12 Carriage Bolts to 58 ft-lb. Torque M12 Hex bolts to 86 ft-lb.			
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.				

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!