



iBoard® Series

INSTALLATION INSTRUCTIONS

PART#: IB-R012

BEFORE INSTALLATION

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED. THANK YOU FOR CHOOSING OUR PRODUCT!

These instructions are provided for reference only. We strongly recommend installation by a professional installer for the best results. We are not responsible for any damage caused during installation.

*ROCKER PANEL MOUNT

*NO DRILLING REQUIRED

Torque Value

Fastener Size	Tightening Torque (ft-lbs)	Required
6mm	6-7	✓
8mm	16-18	✓
10mm	31-32	X
12mm	56-58	X
14mm	92-94	X

Mounting Bracket List

Item	QTY	Bracket Label	Description
1#	2	DFM	Mounting Brackets for Driver /Passenger Front
2#	6	DRM	Mounting Brackets for Driver /Passenger Center /Rear

PART LIST


Driver



Front



Passenger






Hardware Package A (For Bracket Installation)					
Item	QTY	Description	Item	QTY	Description
A1	2	M8X1.25-30mm Hex Flange Bolts	A2	6	M8 Hex Flange Nuts
 A1  A2					

Hardware Package B (For Running Board Installation)					
Item	QTY	Description	Item	QTY	Description
B1	16	M6X1-20mm Square Head Bolts	B3	16	M6 Nylon Lock Nuts
B2	16	M6 Large Flat Washers			
 B1  B2  B3					

STEP 1: Locate the Driver Side Mounting Locations

Starting on the driver side front of the vehicle, Remove existing bolts as shown, (Fig 1).




STEP 2: Install Driver Front Mounting Brackets

Select the Driver Front Mounting Bracket (DFM), install to the 1st location (Figs 1&2) with :

- (1) A1 (M8X1.25-30mm Hex Flange Bolt)
- (1) Re-Use Existing Factory Bolt (Removed on step 1)

Note: Do not fully tighten hardware at this time.

Driver & Passenger Front Mounting Bracket are universal.






STEP 3: Install Driver Center & Rear Mounting Brackets

- (1) Move to the driver side 2nd & 3rd & 4th mounting locations. Repeat **Step 1** to remove existing bolts as shown, (**Fig 1**).
- (2) Select (3) Driver Rear Mounting Bracket (**DRM**), install each Mounting Bracket to the 2nd & 3rd & 4th locations (**Figs 1,3**) with:
 - (1) A2 (M8 Hex Flange Nut)
 - (1) Re-Use Existing Factory Bolt (Removed on step 1)

Note: (6) Mounting Brackets are

universal.




STEP 4: Driver Running Board Installation

Once all (4) mounting brackets are installed, then proceed to the Running Board installation.

- (1) Select a Running Board. Slide (4) B1 M6X1-20mm Square Head Bolts into each bottom channel (**Fig 4**).
- (2) Carefully position the Running Board onto the (4) Mounting Brackets.
- (3) Attach the Running Board to each Mounting Bracket (**Fig 5**) with
 - (2) B1 M6X1-20mm Square Head Bolts
 - (2) B2 M6 Large Flat Washers and
 - (2) B3 M6 Nylon Lock Nuts


Note: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged.

M6X1-20mm Square Head Bolts



(Fig 4) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

(2) B1 (M6X1-20mm Square Head Bolts)
(2) B2 (M6 Large Flat Washers)
(2) B3 (M6 Nylon Lock Nuts)



(Fig 5) Running Board Installed Onto Mounting Bracket

STEP 5: Driver Side Running Board Adjustment

- Level and adjust the Running Board properly.
- Tighten all 6mm hardware with 6-7 ft-lbs torque and 8mm hardware with 16-18 ft-lbs torque.

STEP 6: The Other Side Running Board Installation

Repeat Steps 1-5 for the Other Side Running Board Installation.

And then installation is completed!!!

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use mild soap/non-abrasive products for cleaning only.